





Mini Hi-Fi System with 3CD Changer, 300 Watts Total Power, Logic Deck and wOOx Technology Speaker System

- 2 x 150 watts RMS Stereo
- wOOx Technology Speaker System for deeper bass
- **Sound Navigation** (6 Digital Sound Control, 6 Virtual Environment Control modes and 6 Personal Settings)
- 3-step wOOx Level Control
- 7-Band Spectrum Analyzer with 3 Dim Display modes
- Bass & Treble Control
- 3-way Bass Reflex Speaker System with wOOx Speaker Technology
- 61/2" Top Firing wOOx woofer
- Plays CD, CD-R and CD-RW discs
- Dual Logic Tape Deck with Auto Replay
- · Line Out + Digital Out for perfect CD recording
- Subwoofer Ready
- Eco Power Standby mode (<2 watts)
































Sound Enhancement

2 x 150 Watts RMS Stereo

150 watts continuous RMS power output per channel, at 6 Ohms, from 80Hz-16kHz, with no more than 10% Total Harmonic Distortion (THD).

wOOx Technology

Philips patented wOOx Technology ensures superior bass results. The dual suspension bass radiator, together with dedicated amplifier circuitry, is especially designed to produce and handle high dynamic sound signals at very low frequencies. Because of the dual suspension, the excursion of the membrane can be extreme (see illustration). This, in combination with the symmetrical sandwich construction, provides for very low and precise bass without noticeable distortion. The net effect of using wOOx Technology is a tight bass sound that is significantly "lower and louder" than conventional mini shelf systems.



Sound Navigation

(Jog + DSC + VEC + PS)

The Sound Navigation System is a complete set of sound manipulation tools consisting of

- 6 Digital Sound Control settings: (CLASSIC, ROCK, VOCAL, TECHNO, OPTIMAL, JAZZ),
- 6 Modes Virtual Environment Control: (HALL, DISCO, CONCERT, CINEMA, CLUB, ARCADE)
- 6 Personal Settings: To preserve your favourite sound settings and save them into 6 different memory settings,

Bass & Treble Control

Bass and treble allows sound adjustment of high and low frequencies to personal preferences.

3-Step wOOx Level Control

As the human ear does not perceive low frequencies at the same level as higher frequencies (though at the same "volume"), the bass sound needs to be enhanced to achieve maximum impact. The wOOx is progressively driven at different optimization levels in setting wOOx 1,

3-Way Bass Reflex Speaker System with Bass Radiator

Equipped with one 61/2" woofer for smooth low and mid range reproduction, one 21/2" ferro-fluid cooled tweeter and one 1" Polydome tweeter for crisp high tones. 61/2' top wOOx Bass Radiator entrance bass reproduction together with wOOx Duplication Control.

AM/FM Stereo Digital Tuner

State-of-the-art precision tuning system insures precise, accurate station selection every time, along with the greatest performance and reliability available.

Subwoofer Ready

Affords easy access to greater dimensions in sound with output signals available for connection to a subwoofer.

Convenience

3-CD Changer with Motorized Drawer

Multi-disc play capability provides more than three hours of continuous music.

Plays CD, CD-R and CD-RW discs

The player offers 100% playback guarantee of CD, CD-R and CD-RW discs over the entire lifetime of the player. Even CD-RW audio recordings on computers can be used.

Dual Logic Tape Deck

Offer the ability to switch from one function, such as fast forward, to another function, such as play, by remote control.

Auto Reverse

The feature employs an auto reverse mechanism to sense the end of the tape and automatically reverse the direction of tape travel in the PLAY mode providing an uninterrupted, continuous flow of music without manually flipping the cassette tape.

45-key Remote Control

This infrared remote control operates volume +/-, all CD functions (POWER, NEXT, PREVIOUS, PLAY, STOP, PAUSE, SHUFFLE, REPEAT, PROGRAM, CD123, CD DIRECT 1, 2, 3, ▶▶ and ◄◄), AUX/CDR select, TUNER select, TAPE 1/2 select, TV select, numeric 1 to 9 & 0, CLOCK, AUTO REV., TIMER ON/OFF, SLEEP, DIM, Personal Setting select and sound enhancement features including, Digital Sound Control (DSC), Virtual Environment Control (VEC), BASS/TREBLE, wOOx on/off, wOOx Level, Bass +/- and Treble +/-.

Easy Set

Press Standby 'ON' for 5 secs to automatically program 40 tuner presets. (FM only)

40-Random Channel Presets

Random memory presets allow pre-programming of up to 40 AM and FM station frequencies into the tuner memory.

Auto Store

Automatically stores up to 40 preset FM or AM stations

40-track CD Random Program

Store up to 40 of your favorite CD track selections, from one or multiple discs, to be played back in the order in which they are programmed anytime you like.

Auto Record Level Control

Micro electronic circuitry constantly monitors the final audio amplifier stage to insure accurate, distortion-free recordings every time.

AUX/Video Input

For connection of audio accessory pieces such as a LD UPC Code: 0 3784990 9164 or DVD player, television, or external cassette deck.

Direct Source Selection

Automatically switch to a new source and pause the current source at the touch of a single button.

Demo Mode

Functions always. Press 'STOP' for 5 secs to interrupt demo mode.

Direct Play Button

Allows you to select and play any CD in the carousel by touching only one button.

Shuffle One/All Discs

Plays all selections on a particular disc or multiple discs in multi-disc players in random order, ignoring the sequential order in which they were originally recorded.

Repeat track/disc/all

Repeat your favorite track, disc or all.

Change While Play

Flexiblility of changing 2 discs while still listening to the third disc being played.

One-Touch CD Synchro Recording

One button allows the cassette deck and CD player to communicate with one another to synchronize the start of a recording on an analog audio cassette deck with the start of a CD or a CD program.

Interrupts playback of a CD without returning to the beginning of the disc, so when play resumes, the music begins exactly where it stopped.

Next/Previous Skip

This two button feature offers you the opportunity to skip back to the previous track or skip up to the next track instantly.

High-Speed Dubbing

High-speed dubbing makes it possible to create good quality recordings (dubs) from one tape to another at twice the normal speed in RECORD mode.

Clock, Alarm and Sleeptimer

Set the alarm portion of a built-in digital clock to wake you to music from your favorite CD or an AM/FM radio station at any desired time of the day. Sleeptimer settings of 60, 45, 30 or 15 minutes.

3 Dim Display modes (including nite mode)

2 different display options showing different amounts of display activity can be selected and 1 nite mode display which shows minimal display activity and turns most of the lights off.

Eco Power Standby Mode (<2 watts)

Most systems consume 10-15 watts just on standby. Philips systems consumes less than 2 watts of energy on standby for big savings to the listener.

Product Dimensions: 10.4" W x 12.2" H x 15.4" D (electronics) 9.4" W x 13.8" H x 12.4" D (speakers) Package Dimensions: 21.4" W x 28.3" H x 16.1" D Product weight: 46.3 lbs. Carton contains: 3CD Changer Mini System, Multi-Function Remote Control, Batteries, Operating instructions, Warranty information

Printed in Singapore Date printed : Sep 2000 © 2000 Royal Philips Electronics N.V. All right reserved.
A Division of Philips Electronics North America Corp. Specifications subject to change without

As an ENERGY STAR® Partner Philips has determined that this product meets the ENERGY STAR® quidelines for energy efficiency.

